

MATX	Matrix					
g-shift			EIGVEC	EIGVAL	M.LU	M.QR
f-shift	$\ x\ _p$	UNITV	$[M]^T$	$\bar{x}, \bar{y}$	dot	cross
unshifted	$[M]^{-1}$	MSQRT	RSUM	CSUM	$ M $	VECTOR
Page 2	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/C47/Menus/C47_Menu_MATX_page_1.pdf

Next menu https://47calc.com/doc/C47/Menus/C47_Menu_MATX_page_3.pdf

Ref 1 https://47calc.com/doc/Application%20Notes/AN0020_C47_R47_Matrix_and_Vector.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p2	MATX	MENU	Matrix	Matrix functions ; a matrix is displayed in X and shown in other stack registers as [m×n Matrix] or [m×n ℂ Matrix] when containing complex element(s) ; Ref : https://47calc.com/doc/Application%20Notes/AN0020_C47_R47_Matrix_and_Vector.pdf ; Info : monadic functions work per matrix element (except 1/x, which is a shortcut for [M] ⁻¹ , use -1 y* instead ; and $\sqrt{x}$, which is a shortcut for MSQRT, use 0.5 y* instead) ; in edit mode, all functions work per element ; use registers to input calculation results	Matrix operations		MATX	
F1	[M] ⁻¹	Function (monadic)	Invert matrix	Invert matrix in X (exists only when M ≠ 0) ; Shortcut : [1/x] ; Info : Error 22 -- Singular matrix -- is raised when M = 0	Matrix operations		[M] ⁻¹	
F2	MSQRT	Function (monadic)	Square root of matrix	Square root of matrix in X : if M = MSQRT(X), M × M = X, where × denotes matrix multiplication ; Shortcut : [$\sqrt{x}$] ; Info : Error 20 -- No root found or Error 21 -- Matrix mismatch may be raised (the latter when the matrix is not square)	Matrix operations		M.SQRT	
F3	RSUM	Command	Row sum	Row sum of vector or matrix in X : RSUM = $\sum a_{ij}$	Matrix operations		RSUM	
F4	CSUM	Command	Column sum	Column sum of vector or matrix in X : CSUM = $\sum a_{ij}$	Matrix operations		CSUM	
F5	M	Function (monadic)	Determinant	Determinant of matrix in X (matrix must be square)	Matrix operations		M	
F6	VECTOR	MENU	Vector menu	Vector functions ; Ref : https://47calc.com/doc/C47/Reference/C47_Vector_display.pdf ; Info : Vectors are stored internally as rectangular and calculation results are presented in rectangular format ; to edit a vector, first put it in rectangular format ; vector TI's are shown for values in X only and a small font may be used ; vector TI's are minimised if the stack changes or [EXIT] is pressed (only ijk or r0k or p0p is shown, without subscripts or brackets)	Vector operations		VECTOR	
fF1	$\ x\ _p$	Function (monadic)	Norm	Norm of vector or matrix in X with parameter p (trailing input) = 0, 1, 2, ..., 9, ∞ : 0 : Number of non-zeros of vector or matrix in X : $\ x\ _0 = \sum \mathbb{I}(a_i \neq 0)$, where $\mathbb{I}$ is the indicator function, 1 if true, 0 if false ; 1 : Maximum column sum of absolute element values of a matrix in X : $\ x\ _1 = \max_i \sum_j a_{ij} $; 2 : Euclidean magnitude of a vector in X or Frobenius norm of a matrix in X : $\ x\ _2 = \sqrt{\sum_i \sum_j a_{ij} ^2}$; 3 : $\ x\ _3 = \sqrt[3]{\sum_i \sum_j a_{ij} ^3}$; ... ; 9 : $\ x\ _9 = \sqrt[9]{\sum_i \sum_j a_{ij} ^9}$; ∞ : Maximum row sum of absolute element values of a matrix in X : $\ x\ _\infty = \max_i \sum_j a_{ij} $; TAM : $\ x\ _p$ _ TamNorm menu ; Info : parameter 0, 1, 2, ..., 9, ∞ (use [TamNorm.1] F2 to enter ∞)	Matrix operations		$\ x\ _p$	
fF2	UNITV	Command	Unit vector or matrix	Unit vector or matrix for Real or Complex matrix or vector ; the result will have Euclidean magnitude 1 ; Info : UNITV also applies to Complex numbers	Complex numbers		UNITV	
fF3	[M] ^T	Function (monadic)	Transpose matrix	Transpose matrix in X	Matrix operations		[M] ^T	
fF4	$\angle \vec{x}, \vec{y}$	Function (dyadic)	Vector angle	Angle between the 2D or 3D vectors in X and Y	Matrix operations	3Dxyz	$\angle \vec{x}, \vec{y}$	
fF5	dot	Function (dyadic)	Dot product (·)	Dot product of vectors in X and Y	Complex numbers		DOT	
fF6	cross	Function (dyadic)	Cross product (×)	Cross product of vectors in X and Y	Complex numbers		CROSS	
gF1								
gF2								
gF3	EIGVEC	Function (monadic)	Eigenvector	Eigenvector of matrix in X ; tolerance set by SDIGS (use value of 10 ⁻¹⁶ for better performance or higher for better accuracy) ; Info : Displays : i/m Tol: current/target Iter: n, where i/m is count of eigenvalues, n is iteration counter ; shown if flag MONIT is SET ; for new models and simulator, extended internal eigenvalue precision with 159-digit type integration was added, achieving 39-digit accuracy for 2x2 and 3x3 solvers, but this is not applicable to DM42 hardware	Matrix operations	MONIT	EIGVEC	

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
gF4	EIGVAL	Function (monadic)	Eigenvalues	Eigenvalues as a 1xn vector (returned in X) and as the diagonal elements of an nxn matrix (returned in Y) ; tolerance set by SDIGS (use value of 10-16 for better performance or higher for better accuracy) ; Info : Displays : i/m Tol: current/target Iter: n, where i/m is count of eigenvalues, n is iteration counter ; shown if flag MONIT is SET ; for new models and simulator, extended internal eigenvalue precision with 159-digit type integration was added, achieving 39-digit accuracy for 2x2 and 3x3 solvers, but this is not applicable to DM42 hardware	Matrix operations	MONIT	EIGVAL	
gF5	M.LU	Function (monadic)	LU decomposition	Decompose matrix in X into lower (L) in Y and upper (U or R) matrix in X ; pivot matrix in Z ; Info : LU (LR) factorisation, underlies inversion and linear solving	Matrix operations		M.LU	
gF6	M.QR	Function (monadic)	QR decomposition	Decompose matrix in X into unitary (Q) in Y and upper (R) matrix in X ; Info : QR factorisation, underlies eigenvalue computation	Matrix operations		M.QR	

p2	MATX	Link
F1	$[M]^{-1}$	
F2	MSQRT	
F3	RSUM	
F4	CSUM	
F5	$ M $	
F6	VECTOR	https://47calc.com/doc/C47/Menus/C47_Menu_VECTOR_page_1.pdf
fF1	$\ x\ _p$	
fF2	UNITV	
fF3	$[M]^T$	
fF4	$\angle \vec{x}, \vec{y}$	
fF5	dot	
fF6	cross	
gF1		
gF2		
gF3	EIGVEC	
gF4	EIGVAL	
gF5	M.LU	
gF6	M.QR	