

PLSTAT	Plot statistics					
g-shift	-ZOOM ₀	+ZOOM ₀				
f-shift	X:Y=1 ☐	PLTRST				
unshifted	X.AXIS ☐	Y.AXIS ☐				
Page 1	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/C47/Menus/C47_Menu_PLOT_page_2.pdf

Next menu https://47calc.com/doc/C47/Menus/C47_Menu_PLSTAT_page_2.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p1	PLSTAT	MENU (item)	Plot statistics	Plot statistics matrix (STATS, programmable) ; TI : Calculating graph coordinates ... may be shown when plotting the statistics matrix ; Info : in Program Entry Mode, use PAUSE, SNAP or PLTFCNS to view the plot (PLTFCNS also displays the plot options menu) ; when SDIGS is set to the maximum value of 34, plotting uses 15 instead, otherwise it uses the value set by SDIGS ; Ref : https://47calc.com/doc/Application%20Notes/AN0003_C47_JM_Graphing.pdf	Plotting and statistics		PLSTAT	
F1	X.AXIS □	Setting	Autoscaling to show x-axis	Switch on autoscaling to show x-axis ; not programmable - in PEM, use flag PLx.ax ; Info : axis 0.0 or x-axis y=0 or y-axis x=0 is displayed	Plotting	PLx.ax		OFF
F2	Y.AXIS □	Setting	Autoscaling to show y-axis	Switch on autoscaling to show y-axis ; not programmable - in PEM, use flag PLy.ax ; Info : axis 0.0 or x-axis y=0 or y-axis x=0 is displayed	Plotting	PLy.ax		OFF
F3								
F4								
F5								
F6								
fF1	X:Y=1 □	Setting	Forcing autoscale	Switch on forcing autoscale on x- and y-axis to be the same ; not programmable - in PEM, use flag PLxy:1	Plotting	PLxy:1		OFF
fF2	PLTRST	Command (PEM)	Reset plot	Reset all plot options and redraw graph ; Info : Resets options for lines, boxes, crosses, plusses and scaling ; PLTRST also resets ↓Y and ↑Y to zero	Plotting		PLTRST	
fF3								
fF4								
fF5								
fF6								
gF1	-ZOOM ₀	Command	Zoom out on y-axis	Decrease zoom level on the y-axis (range -16 to +16) ; Info : <0 : zoom out ; 0 : normal ; >0 : zoom in ; -ZOOM resets ↑Y and ↓Y to zero	Plotting			0
gF2	+ZOOM ₀	Command	Zoom in on y-axis	Increase zoom level on the y-axis (range -16 to +16) ; Info : <0 : zoom out ; 0 : normal ; >0 : zoom in ; +ZOOM resets ↑Y and ↓Y to zero	Plotting			0
gF3								
gF4								
gF5								
gF6								