

Draw _Y ^X (PLFUNC)	Draw (stack limits)					
g-shift	-ZOOM ₀	+ZOOM ₀				
f-shift	X:Y=1 □	PLTRST				
unshifted	↓X -10	↑X 10				
Page 1	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/R47/Menus/R47v0_Menu_Draw_page_4.pdf

Next menu https://47calc.com/doc/R47/Menus/R47v0_Menu_DrawYX_page_2.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p1	Draw _y ^x (PLFUNC)	MENU (item)	Draw (stack limits)	Draw graph for expression (or equation) entered in the equation editor ; X-axis limits set from stack (Y, X) and Y-axis limits by variables (↓Y, ↑Y) ; Info : In Program Entry Mode, use PAUSE, SNAP or PLTFCNS to view the plot ; when SDIGS is set to the maximum value of 34, plotting uses 15 instead, otherwise it uses the value set by SDIGS ; if an equation was entered (containing "="), the left hand side is plotted	Plotting		Draw _y ^x	
F1	↓X ₋₁₀	Variable (real)	Lower limit for X-axis	Reserved Real variable for the lower limit for X-axis (↓X) ; set interactively from menu Graphs and set by Draw _y ^x ; TI : '↓X' :	Plotting		↓X	-10
F2	↑X ₁₀	Variable (real)	Upper limit for X-axis	Reserved Real variable for the upper limit for X-axis (↑X) ; set interactively from menu Graphs and set by Draw _y ^x ; TI : '↑X' :	Plotting		↑X	10
F3								
F4								
F5								
F6								
fF1	X:Y=1 □	Setting	Forcing autoscale	Switch on forcing autoscale on x- and y-axis to be the same ; not programmable - in PEM, use flag PLxy:1	Plotting	PLxy:1		OFF
fF2	PLTRST	Command (PEM)	Reset plot	Reset all plot options and redraw graph ; Info : Resets options for lines, boxes, crosses, plusses and scaling ; PLTRST also resets ↓Y and ↑Y to zero	Plotting		PLTRST	
fF3								
fF4								
fF5								
fF6								
gF1	-ZOOM ₀	Command	Zoom out on y-axis	Decrease zoom level on the y-axis (range -16 to +16) ; Info : <0 : zoom out ; 0 : normal ; >0 : zoom in ; -ZOOM resets ↑Y and ↓Y to zero	Plotting			0
gF2	+ZOOM ₀	Command	Zoom in on y-axis	Increase zoom level on the y-axis (range -16 to +16) ; Info : <0 : zoom out ; 0 : normal ; >0 : zoom in ; +ZOOM resets ↑Y and ↓Y to zero	Plotting			0
gF3								
gF4								
gF5								
gF6								