

C47 Ref page : Keyboard Keys USERMODE XFN with main key showing unshifted keyboard

	1	1	1	2	2	2	3	3	3	4	4	4	5	5	5	6	6	6	
1	F1			F2			F3			F4			F5			F6			1
2	+I a ^{b/c}			XPOWER # BIN			XSQR .ms			X10 ^{-X} .d DEC			Xe ^X LBL			[α] GT0 FP			2
2	X→XFN A			X1/X B			XSQRT C			XLOG D			XLN E			XEQ F			2
2	a Σ {A}			b ^ {B}			c √ {C}			d LOG {D}			e LN {E}			f α [TamAlpha]			2
3	x 4			% Δ% HEX			Xπ XXRTY IP			XASIN i			XACOS →R			XATAN →P			3
3	3STO G			3RCL H			3DROP I			XSIN J			XCOS K			XTAN L			3
3	g {G}			h Δ {H}			i π {I}			j SIN {J}			k COS {K}			l TAN {L}			3
4	COMPLEX [CPX]			DEC LASTx [STK]			[MODE] [TRG]			[DISP] [EXP] OCT			↵ [CLR] ←			←			4
4	ENTER			ENTER 3SWAP M			XCHS N			E O			←			←			4
4	X.EDIT ←			ENTER m ↵ {M}			n ± {N}			o <E> {O}			CLA CLA ←			←			4
5	≡Δ REGS			[EQN] [HOME] 7			[ADV] [FIN] 8			[MATX] [X.FN] 9			[STAT] [PLOT]			XDIV S			5
5	▲ (HOME←)			7 P			8 Q			9 R			XDIV S			÷ ÷			5
5	CASE UP ↑ (α ^{SUP}) ▲			p 7 7			q 8 8			r 9 9			s ÷ ÷			÷ ÷			5
6	≡▽ FLGS			[BASE] [BITS] 4			[CONV] [CLK] 5			[FLAG] [REAL] 6			[PROB] [INTS]			XMULT W			6
6	▼ (END→)			4 T			5 U			6 V			XMULT W			x x			6
6	CASE DN ↓ (α _{SUB}) ▼			t 4 4			u 5 5			v 6 6			w x x			x x			6
7	f/g			ASN [KEYS] 1			USER [α.FN] 2			[P.FN] [LOOP] 3			[PRINT] [I/O]			XSUB -			7
7	f/g			1 X			2 Y			3 Z			XSUB -			- -			7
7	<f>lipchar di<g>it f/g			x 1 1			y 2 2			z 3 3			e - -			- -			7
8	OFF SNAP EXIT			VIEW STOPW 0			SHOW [INFO]			PRGM [TEST]			[CAT] [CNST]			XADD =			8
8	EXIT			0 :			. ,			R/S ?			XADD =			=			8
8	OFF SNAP EXIT			; 0 0			# . .			! /			[CAT] + +			+ +			8
	1	1	1	1	1	1	2	2	2	3	3	3	4	4	4	5	5	5	

Shortcut for menu HOME : triple [f/g] (because HOME^α is SET); longerpress [f/g] (because HOME^α is SET)

Shortcut for menu MyM : PEM longer [EXIT]

TAM shortcut letters {A}, {B}, etcetera are applicable to both registers and flags

f	g	#TAM
unshifted		alpha
alpha f	alpha g	TAM