

→ (TamIndirect)	Indirection					
g-shift						REG
f-shift						
unshifted		VAR	X	Y	Z	T
Page 1	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/C47/Menus/C47_Menu_alphaMisc_page_2.pdf

Next menu https://47calc.com/doc/C47/Menus/C47_Menu_Integral-f_page_1.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p1	→ (TamIndirect)	Command (TAM)	Indirection	Presented in TAM menus for commands accessing indirect input ; Info : Opens TamIndirect menu for the command that activated the current TAM menu	Trailing input			
F1								
F2	VAR	MENU (ASM)	VAR	Presented in TAM menus for commands accessing variables ; TAM : CAT.VARS.* menu ; Info : Type characters 1-2 to search ; Matrix variables STATS and HISTO are also included in this menu, if created	Trailing input		VAR	
F3	X	EasyAccess (TAM)	Register X	Easy access to Register X (100) : Stack level 1 ; TI : X:	Trailing input			
F4	Y	EasyAccess (TAM)	Register Y	Easy access to Register Y (101) : Stack level 2 ; TI : Y:	Trailing input			
F5	Z	EasyAccess (TAM)	Register Z	Easy access to Register Z (102) : Stack level 3 ; TI : Z:	Trailing input			
F6	T	EasyAccess (TAM)	Register T	Easy access to Register T (103) : Stack level 4 ; TI : T:	Trailing input			
fF1								
fF2								
fF3								
fF4								
fF5								
fF6								
gF1								
gF2								
gF3								
gF4								
gF5								
gF6	REG	MENU (TAM)	TAM (register)	Presented in TAM menus to quickly select lettered registers ; Info : Shortcut {A} indicates character key A (in TAM), etcetera ; Ref : https://47calc.com/doc/C47/Reference/C47_Registers.pdf	Trailing input			

p1	→ (TamIndirect)	Link
F1		
F2	VAR	https://47calc.com/doc/C47/Menus/C47_Menu_VAR_page_1.pdf
F3	X	
F4	Y	
F5	Z	
F6	T	
ff1		
ff2		
ff3		
ff4		
ff5		
ff6		
gf1		
gf2		
gf3		
gf4		
gf5		
gf6	REG	https://47calc.com/doc/C47/Menus/C47_Menu_REG_page_1.pdf