

CFLG (SYS.FL)	Configuration flags					
g-shift						
f-shift						
unshifted	 ACT ₀	 EN ☐	 NORM ☐	 TRACE ☐		
Page 7	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/C47/Menus/C47_Menu_CFLG_page_6.pdf

Next menu https://47calc.com/doc/C47/Menus/C47_Menu_CHARS_page_1.pdf

Ref 1 https://47calc.com/doc/Application%20Notes/AN0028_C47_R47_JM_Configurability_Tour.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p7	CFLG (SYS.FL)	MENU (item, nonpgm)	Configuration flags	Activate menu for setting system flags using FF (Flip flag) function ; Ref : https://47calc.com/doc/Application%20Notes/AN0028_C47_R47_JM_Configurability_To-ur.pdf	Flags		SYS.FL	
F1	ACT	Flag (system)	Print port active	SET for infrared print port active ; CLEAR for infrared print port inactive ; Info : If flag ACT is SET, the infrared port is enabled ; if CLEAR, the infrared port is disabled	Printing	ACT		CLEAR
F2	EN	Flag	Printing enabled	SET for printing enabled ; CLEAR for printing disabled	Printing	EN		CLEAR
F3	NORM	Flag	Printer mode Normal/Trace	SET for printer mode Normal (flag TRACE is CLEAR) or printer mode Stack trace (flag TRACE is SET) ; CLEAR for printer mode Manual (flag TRACE is CLEAR) or printer mode Trace (flag TRACE is SET) ; Info : There are four print modes : MAN, NORM, TRACE and STRACE, which are set by two flags : TRACE and NORM	Printing	NORM		CLEAR
F4	TRACE	Flag	Printer mode Trace/Stack trace	SET for printer mode Trace (flag NORM is CLEAR) or printer mode Stack trace (flag NORM is SET) ; CLEAR for printer mode Manual (flag NORM is CLEAR) or printer mode Normal (flag NORM is SET) ; Info : There are four print modes : MAN, NORM, TRACE and STRACE, which are set by two flags : TRACE and NORM	Printing	TRACE		CLEAR
F5								
F6								
fF1								
fF2								
fF3								
fF4								
fF5								
fF6								
gF1								
gF2								
gF3								
gF4								
gF5								
gF6								