

MyM	MyMenu					
g-shift						
f-shift						
unshifted	DMCP	ActUSB	SAVE	LOAD	SAVEST	LOADST
Page 4	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/C47/Menus/C47_Menu_MyMenu_page_3.pdf

Next menu https://47calc.com/doc/C47/Menus/C47_Menu_MyMenu_page_5.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p4	MyM	MENU	MyMenu	User menu presenting a ribbon to quickly access user selected functions (and menus) ; all buttons are user assignable ('riveted' look) ; set by RIBBONS ; reset using MyMR ; default ribbon M.C47 ; Shortcut : PEM longer [EXIT] ; longpress [EXIT] ; NIM long [EXIT] ; during assignment, pressing USER (f[2]) opens MyMenu ; Info : ribbons are documenten on page 1 : M.CPX ; 2 : M.ENG ; 3 : M.FIN ; 4 : M.SAV ; 5 : M.C47 ; 6 : M.R47 ; 7 : M.FIN+ ; 8 : M.SAV+	Customisation		MyMenu	
F1	DMCP	Command (HW)	Access DMCP menu	Access DMCP menu ; hardware only ; use EXIT to return without RESET -- see https://technical.swissmicros.com/dm42/doc/dm42_user_manual.html#dmcp_sys_menu ; Info : Error 126 -- Not available on the simulator -- is raised when this command is performed on the simulator ; Ref : https://47calc.com/doc/C47/Reference/C47_DMCP_menu.pdf	System		DMCP	
F2	ActUSB	Command (HW)	Activate USB disk	Activate USB disk without exiting to DMCP ; hardware only ; Info : Error 126 -- Not available on the simulator -- is raised when this command is performed on the simulator	System		ActUSB	
F3	SAVE	Command (nonpgm)	Save full backup	Save full backup to file SAVFILES/C47.sav in FAT ; TI : Saved ; Directory : SAVFILES/	Input-Output		SAVE	
F4	LOAD	Command (nonpgm)	Load full backup	Load full backup from SAVE file SAVFILES/C47.sav in FAT and auto-clear USER mode ; key assignments will be ignored when loading from a backup file created on a different model (C47 versus R47 and vice versa) ; TI : Backup restored + <version info> ; Directory : SAVFILES/	Input-Output		LOAD	
F5	SAVEST	Command (nonpgm)	Save full state file	Save backup file (.s47) in FAT for LOADST ; the state file contains the complete state of the calculator: all memory content (registers, variables, programs, equations), all user assignments (key assignments, user menus) and all settings ; TI : Saving state file ... ; Saved ; DMCP File save dialog ("Save Calculator State" -- STATE/)	Input-Output		SAVEST	
F6	LOADST	Command (nonpgm)	Load state	Load state from SAVEST backup file (.s47) in FAT and clear USER mode ; if full state, presenting "WARNING: Current calculator state will be lost. Press [ENTER] to confirm." ; key assignments will be ignored when loading from a state file created on a different model (C47 versus R47 and vice versa) ; TI : Loading state file ... ; State file loaded ; DMCP File open dialog ("Load Calculator State" -- STATE/)	Input-Output		LOADST	
fF1								
fF2								
fF3								
fF4								
fF5								
fF6								
gF1								
gF2								
gF3								
gF4								
gF5								
gF6								