

PRINT	Printing					
g-shift			MAN 	NORM 	TRACE 	STRACE 
f-shift						
unshifted						
Page 1	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/C47/Menus/C47_Menu_Prefix_page_1.pdf

Next menu https://47calc.com/doc/C47/Menus/C47_Menu_PRINT_page_2.pdf

Ref 1 https://47calc.com/doc/Application%20Notes/AN0021_C47_R47_DL_Printing.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p1	PRINT	MENU	Printing	Printing functions ; Info : Printing is available for new models and simulator, but is currently available on DM42 hardware only in some packages ; Ref : https://47calc.com/doc/Application%20Notes/AN0021_C47_R47_DL_Printing.pdf	Printing		PRINT	
F1	ADV	Command	Printer advance	Advance print paper, after printing the contents of the print buffer ; Info : SBI is shown if flag SBprn is SET ; SBI :	Printing		ADV	
F2	STK	Command	Print stack	Print stack registers, labeled, in TZYX or DCBA TZYX order, depending on stack size set by SSIZE8 ; Info : If OFF, writes stack to file in DATA/<YYYYMMDD-HHMMSS00>.REGS.TSV ; SBI ; 8 ; 4 is shown if flag SBprn is SET ; SBI : ; 8 ; 4	Printing	SSIZE8	STK	
F3	x	Command	Print X	Print X register, marked with *** ; Info : If OFF, writes X to file in DATA/<YYYYMMDD-HHMMSS00>.REGS.TSV ; SBI is shown if flag SBprn is SET ; SBI :	Printing		x	
F4	r	Command	Print register or variable	Print single register or variable, labeled with the register or variable name ; TAM : r Tam menu ; Info : if OFF, writes register or variable to file in DATA/<YYYYMMDD-HHMMSS00>.REGS.TSV ; SBI is shown if flag SBprn is SET ; SBI :	Printing		r	
F5	α	Command	Print alpha	Print contents of register or variable as text ; Info : If OFF, α writes alpha to file in DATA/<YYYYMMDD-HHMMSS00>.REGS.TSV ; SBI is shown if flag SBprn is SET ; SBI :	Printing		α	
F6	PROG	Command (nonpgm)	Print program	Print program, with date and time printed at the top of the listing ; TAM : PROG TamLbOnly menu ; Info : If OFF, executes XPORTP ; [EXIT] or [R/S] can be pressed at any time to stop the listing ; in printer mode Trace, the program listing is printed in condensed form ; SBI is shown if flag SBprn is SET ; SBI :	Printing		PROG	
fF1	ON O	Setting (pgm)	Printing ON	Switch on printing and send commands to infrared print port ; Info : ON sets flag ACT (infrared print port active) and EN (printing enabled)	Printing	ACT	ON O	OFF
fF2	OFF @	Setting (pgm)	Printing OFF	Switch off printing and print to file (selected commands) ; Info : OFF clears flag ACT (infrared print port inactive) and EN (printing disabled) ; Error 63 -- Printing Is Disabled -- may be shown when executing a print command	Printing	ACT	OFF @	OFF
fF3	#	Command	Print byte	Print single byte (value 0-255), to be used as character or ESC sequence ; TAM : # TamNonReg menu ; Info : SBI is shown if flag SBprn is SET ; SBI :	Printing		#	
fF4								
fF5	CHAR	Command	Print character	Print single character from Unicode value specified in a register or variable ; TAM : CHAR Tam menu ; Info : only characters in the C47 standard font are supported ; SBI is shown if flag SBprn is SET ; SBI :	Printing		CHAR	
fF6	LIST	Command (nonpgm)	Print list	Print specified number of lines of current program ; TAM : LIST TamNonReg menu ; Info : [EXIT] or [R/S] can be pressed at any time to stop the listing ; in printer mode Trace, the program listing is printed in condensed form ; SBI is shown if flag SBprn is SET ; SBI :	Printing		LIST	
gF1	82240	MENU	Printer control	Printer control ; the menu button, e.g. on [PRINT.1] gF1 shows the default printer selected : 82240 ; Info : Printing is available for new models and simulator, but is currently available on DM42 hardware only in some packages	Printing			82240
gF2								
gF3	MAN @	Setting (pgm)	Printer mode Manual	Switch on printer mode Manual (flag TRACE is CLEAR and flag NORM is CLEAR) ; Info : In MAN mode, the printer is idle and only prints when a print command is executed ; VIEW and AVIEW can also generate print output in this mode	Printing	NORM	MAN @	ON
gF4	NORM O	Setting (pgm)	Printer mode Normal	Switch on printer mode Normal (flag TRACE is CLEAR and flag NORM is SET) ; Info : In NORM mode, the printer prints numbers and alpha strings that are keyed in, names of functions executed from the keyboard and output from print functions ; running programs only print from print commands or from PROMPT	Printing	NORM	NORM O	OFF

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
gF5	TRACE O	Setting (pgm)	Printer mode Trace	Switch on printer mode Trace (flag  TRACE is SET and flag  NORM is CLEAR) ; Info : In TRACE mode, the printer prints numbers and alpha strings that are keyed in, names of functions executed from the keyboard, intermediate and final results and output from print functions ; if a program is running, each step is printed as it executes ; in this mode, program listings are printed in condensed form	Printing	 TRACE	TRACE O	OFF
gF6	STRACE O	Setting (pgm)	Printer mode Stack trace	Switch on printer mode Stack trace (flag  TRACE is SET and flag  NORM is SET) ; Info : In STRACE mode, the printer prints the stack and alpha strings that are keyed in, names of functions executed from the keyboard, intermediate and final results and output from print functions ; if a program is running, each step is printed as it executes ; in this mode, program listings are printed in condensed form	Printing	 TRACE	STRACE O	OFF

p1	PRINT	Link
F1	ADV	
F2	STK	
F3	x	
F4	r	
F5	α	
F6	PR0G	
fF1	ON ○	
fF2	OFF ●	
fF3	#	
fF4		
fF5	CHAR	
fF6	LIST	
gF1	82240	https://47calc.com/doc/C47/Menus/C47_Menu_Printer_page_1.pdf
gF2		
gF3	MAN ●	
gF4	NORM ○	
gF5	TRACE ○	
gF6	STRACE ○	