

TamShuffle	TAM mode (shuffle)					
g-shift						
f-shift						
unshifted			X	Y	Z	T
Page 1	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/C47/Menus/C47_Menu_TamRclTVM_page_1.pdf

Next menu https://47calc.com/doc/C47/Menus/C47_Menu_TamSto_page_1.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p1	TamShuffle	MENU (TAM)	TAM mode (shuffle)	Transient Alpha Mode is activated for trailing input (shuffle) ; Info : TamShuffle menu is typically activated by $\bar{x}$ on [STK.1] fF6	Trailing input			
F1								
F2								
F3	X	EasyAccess (TAM)	Register X	Easy access to Register X (100) : Stack level 1 ; TI : X:	Trailing input			
F4	Y	EasyAccess (TAM)	Register Y	Easy access to Register Y (101) : Stack level 2 ; TI : Y:	Trailing input			
F5	Z	EasyAccess (TAM)	Register Z	Easy access to Register Z (102) : Stack level 3 ; TI : Z:	Trailing input			
F6	T	EasyAccess (TAM)	Register T	Easy access to Register T (103) : Stack level 4 ; TI : T:	Trailing input			
fF1								
fF2								
fF3								
fF4								
fF5								
fF6								
gF1								
gF2								
gF3								
gF4								
gF5								
gF6								