

C47 Ref page : Font browser -- FBR in menu [α.FN.1] F1
 Use x→α in menu [α.FN.1] F3 ; blue characters are FBR-only

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0020	^s _p	!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/
0030	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
0040	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
0050	P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	_
0060		a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
Numeric font. Press ↓ or EXIT																

1/41

^s designates the space character

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0070	p	q	r	s	t	u	v	w	x	y	z				~	⓪
00A0		ı	¢	£		¥		§								
00B0	°	±				μ		•								ı
00D0								×	∅							
00E0															î	
Numeric font. Press ↑, ↓ or EXIT																
																2/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00F0								÷								
0130						ĵ		ĥ								
0170						ŵ		ŷ								
0230			ȳ	ȳ												
02B0	h			r									,			
Numeric font. Press ↑, ↓ or EXIT																
																3/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
02E0				×												
0370									̄	̂						̄
0380	̄	̄	̄	̄								̂		̂		
0390		A	B	Γ	Δ	E	Z	H	Θ	I	K	Λ	M	N	Ξ	O
03A0	Π	P	û	Σ	T	Y	Φ	X	Ψ	Ω						
Numeric font. Press ↑, ↓ or EXIT																
																4/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
03B0		α	β	γ	δ	ε	ζ	η	θ	ι	κ	λ	μ	ν	ξ	ο
03C0	π	ρ		σ	τ	υ	φ	χ	ψ	ω						
03D0		ϑ				ϕ		ϒ	ϙ				Ƒ	Ƒ		
03E0	ϣ	ϣ														
1D40	Τ													g		
Numeric font. Press ↑, ↓ or EXIT																
																5/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
1DA0	f															
1E90													f			g
2000																
2010									(	)			“	”		”
2020																

Numeric font. Press ↑, ↓ or EXIT

6/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2070				E												
2080	0	1	2	3	4	5	6	7	8	9	+	-				*
2090															∞	
20A0													€			∞
2100			©												h	ħ
Numeric font. Press ↑, ↓ or EXIT																
																7/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2110	I			l		N					Q			R		
2120					Z	z										
2140						D		e	i	j						
2160	0	1	2	3	4	5	6	7	8	9	+	-				
2190	←	↑	→	↓												
Numeric font. Press ↑, ↓ or EXIT																
																8/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
21C0	➔				➤				⬆		⬇					
21D0			➡		↔											
2200						∅										∏
2210		Σ								.	√	∛	∜		∞	
2220		ℤ									∫					
Numeric font. Press ↑, ↓ or EXIT																
																9/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2240									≈							
2260	≠				≤	≥										
2290						⊕	α	δ	μ		⊙					
22C0						•										
2390					≡					☰						
Numeric font. Press ↑, ↓ or EXIT																
																10/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
23A0		[		[	]		]									
23E0							À									
23F0		⌚														
2420								⌘	•	;				UK	US	
2460	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Numeric font. Press ↑, ↓ or EXIT																
																11/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2470					0	1	2	3	4	5	6	7	8	9	10	
2480			a	b	c	d	e	f	g	h	i	j	k	l	m	n
2490	o	p	q	r	s	t	u	v	w	x	y	z	a	b	c	d
24A0	e	f	g	h	i	j	k	l	m	n	o	p	q	r	s	t
24B0	u	v	w	x	y	z	A	B	C	D	E	F	G	H	I	J
Numeric font. Press ↑, ↓ or EXIT																
																12/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
24C0	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z
24D0	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P
24E0	Q	R	S	T	U	V	W	X	Y	Z	0					
24F0						1	2	3	4	5	6	7	8	9	-	+
2670											⌂					
Numeric font. Press ↑, ↓ or EXIT																
																13/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2780									,	.						
29D0							⌂									
2B60	←	↑	→	↓												
2C60					π	π	πr									V
Numeric font. Press ↑, ↓ or EXIT																
																14/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0020	^s _p			#								+	,	-	.	/
0030	0	1	2	3	4	5	6	7	8	9						
0040		A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
0050	P	Q	R	S	T	U	V	W	X	Y	Z					-
0060		a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
Numeric font bold. Press ↑, ↓ or EXIT																
																15/41

^s designates the space character

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0070	p	q	r	s	t	u	v	w	x	y	z					
00B0								.								
00D0								x								
2080	0	1	2	3	4	5	6	7	8	9						
2120					ℤ											
Numeric font bold. Press ↑, ↓ or EXIT																
																16/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2140									<i>i</i>	<i>j</i>						
2160	0	1	2	3	4	5	6	7	8	9	+	-				
2210															∞	
2220		4														
2240									≈							
Numeric font bold. Press ↑, ↓ or EXIT																
																17/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2460	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
2470				0	1	2	3	4	5	6	7	8	9	10		
Numeric font bold. Press ↑, ↓ or EXIT																
																18/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0020	^s p	!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/
0030	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
0040	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
0050	P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	_
0060		a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
0070	p	q	r	s	t	u	v	w	x	y	z	{		}	~	Ⓢ
00A0		;	¢	£		¥		§		©		«	¬			
00B0	°	±				μ		•				»	¼	½		¿
Standard font. Press ↑, ↓ or EXIT																
19/41																

Ⓢ designates the space character

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00C0	À	Á	Â	Ã	Ä	Å	Æ	Ç	È	É	Ê	Ë	Ì	Í	Î	Ï
00D0	Ð	Ñ	Ò	Ó	Ô	Õ	Ö	×	Ø	Ù	Ú	Û	Ü	Ý	Þ	ß
00E0	à	á	â	ã	ä	å	æ	ç	è	é	ê	ë	ì	í	î	ï
00F0	ð	ñ	ò	ó	ô	õ	ö	÷	ø	ù	ú	û	ü	ý	þ	ÿ
0100		ā	Ă	ă	Ą	ą	Ć	ć					Č	č	Ď	ď
0110	Đ	đ	Ē	ē	Ě	ě	È	é	Ė	ė	Ĕ	ĕ			Ğ	ğ
0120								Ħ			Ī	ī	Ĭ	ĭ	Į	į
0130	İ	ı				Ĵ		Ķ			Í			Ĺ	ĺ	
Standard font. Press ↑, ↓ or EXIT																
																20/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0140		Ł	ł	Ń	ń			Ň	ň				Ō	ō	Ǫ	ǫ
0150			Œ	œ	Ř	ř		Ř	ř	Š	š				Š	š
0160	Š	š	Ť	ť	Ť	ť			Ů	ů	Ů	ů	Ů	ů	Ů	ů
0170			Ů	ů	Ů	ů	Ů	ů	Ů	ů	Ů	ů	Ů	ů	Ů	ů
0230			Ů	ů												
0280																Ů
0290																Ů
02B0	h			r												

Standard font. Press ↑, ↓ or EXIT

21/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
02E0				×												
0370									̄	̂						̄
0380	Ū	Ȫ	Ū	̄								Ŷ		Ẑ		
0390	İ	À	Β	Γ	Δ	Ε	Ζ	Η	Θ	Ι	Κ	Λ	Μ	Ν	Ξ	Ο
03A0	Π	Ρ	Ū	Σ	Τ	Υ	Φ	Χ	Ψ	Ω	İ	Ȫ	ά	έ	ή	ί
03B0	Û	α	β	γ	δ	ε	ζ	η	θ	ι	κ	λ	μ	ν	ξ	ο
03C0	π	ρ	ς	σ	τ	υ	φ	χ	ψ	ω	ï	ü	ó	ú	ώ	
03D0		θ					φ		ο	ο			Ƒ	Ƒ		
Standard font. Press ↑, ↓ or EXIT																
																22/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
03E0	3	4														
0450	(α) m	* n	-1 d	* k	* i	=	2 p	2 a	2 a	x	A					
1D00					C	D										
1D10												T				
1D20			z													
1D40	T													9		
1DA0	f															
1E90														f		g
Standard font. Press ↑, ↓ or EXIT																
																23/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2000																
2010									‘	’		‘	“	”		”
2020					.		...	l								
2070				E												
2080	0	1	2	3	4	5	6	7	8	9	+	-				*
2090															∞	∞
20A0													€			
2100			©												h	h
Standard font. Press ↑, ↓ or EXIT																
																24/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2110	I			l		N					Q			R		
2120					Z	z										
2130									T							
2140						D		e	i	j						
2160	0	1	2	3	4	5	6	7	8	9	+	-				
2190	←	↑	→	↓	↔	↕										
21B0						↶										
21C0	→				↷				△		▽	≡				
Standard font. Press ↑, ↓ or EXIT																
																25/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
21D0			⇒		⇔											
21E0	↔	↑	↔	↓				↑		↓						
2200		∫	∂	∃	∂	∅		∇	€	€		∃	∂		∫	∏
2210		Σ		±				°	•	✓	3✓	×✓	α	∞	∞	⊥
2220	∠	4	4					Λ	γ	∩	∪	∫	∫	∫	∫	∫
2230	∫						:									
2240				≈					≈							
2250					≡				≡	≡						
Standard font. Press ↑, ↓ or EXIT																
																26/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2260	≠	≡			≦	≧					«	»				
2280			Ɔ		Ɔ											
2290						⊕	α	δ	μ	⊙	⊙					
22A0			┐		┐											
22B0												ŷ	Ȧ	Ȧ		
22C0						•										
2310											⌚	⌚				
2380													↩			
Standard font. Press ↑, ↓ or EXIT																
																27/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2390				⋯						📄						
23A0		⌈	⌋	⌌	⌍	⌎	⌏									
23B0						⌐										
23E0							⌑									
23F0		⌒										⌔				
2400					⌕						⌖					
2410												⌗				
2420		⌘	⌙	⌚		⌛	⌜	⌝	⌞	⌟	⌠	⌡	⌢	⌣	⌤	⌥
Standard font. Press ↑, ↓ or EXIT																
																28/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2430																
2460	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
2470														10		
2480			a	b	c	d	e	f	g	h	i	j	k	l	m	n
2490	o	p	q	r	s	t	u	v	w	x	y	z	a	b	c	d
24A0	e	f	g	h	i	j	k	l	m	n	o	p	q	r	s	t
24B0	u	v	w	x	y	z	A	B	C	D	E	F	G	H	I	J
24C0	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z
Standard font. Press ↑, ↓ or EXIT																
																29/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
24D0	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P
24E0	Q	R	S	T	U	V	W	X	Y	Z	0					
2590																
25A0																
25B0																
25C0																
25E0																
2610																
Standard font. Press ↑, ↓ or EXIT																
																30/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2670											♻️	♻️			♻️	
2710				✓												
2780									,	.						
29B0																⊗
29D0							⌘									
29F0	x y	z														
2B60	←	↑	→	↓												
					π	π	π									∇
Standard font. Press ↑, ↓ or EXIT																
																31/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0020	^s _p	!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/
0030	Ø	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
0040	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
0050	P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	_
0060	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
0070	P	q	r	s	t	u	v	w	x	y	z	{		}	~	
00A0		i	¢	£	¤	¥	¦	§	¨	©	ª	«	¬	­	®	¯
00B0	°	±	²	³	´	µ	¶	·	¸	¹	º	»	¼	½	¾	¿
Tiny font. Press ↑, ↓ or EXIT 32/41																

^s designates the space character

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00C0	À	Á	Â	Ã	Ä	Å	Æ	Ç	È	É	Ê	Ë	Ì	Í	Î	Ï
00D0	Ð	Ñ	Ò	Ó	Ô	Õ	Ö	×	Ø	Ù	Ú	Û	Ü	Ý	Þ	ß
00E0	à	á	â	ã	ä	å	æ	ç	è	é	ê	ë	ì	í	î	ï
00F0	ð	ñ	ò	ó	ô	õ	ö	÷	ø	ù	ú	û	ü	ý	þ	ÿ
0100		ā	ă	ǎ	Ȧ	Ȧ	Ó	Ć	Ĉ	Ĉ	Č	Č	Č	Č	Ď	ď
0110	Đ	đ	Ē	ē	Ě	ě	È	è	Ě	ě	Ě	ě	Ĝ	ğ	Ğ	ğ
0120	Ġ	ğ	Ģ	ģ	Ĥ	ĥ	Ħ	ħ	İ	ı	İ	ı	İ	ı	İ	ı
0130	İ	ı								Ł	ł			Ł	ł	
Tiny font.	Press ↑, ↓ or EXIT															33/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0140		Ł	ł	Ń	ń			Ň	ň				Ŏ	ŏ	Ǫ	ǫ
0150			Œ	œ	Ř	ř			Ř	ř	Ś	ś			Ş	ş
0160	Š	š	Ť	ť	Ť	ť			Ů	ů	Ů	ů	Ů	ů	Ô	ô
0170			Ů	ů	Ů	ů	Ů	ů	Ů	ů	Ž	ž	Ž	ž	Ž	ž
0190			ƒ													
0230			Ÿ	Ź												
0370									Ẃ	ẃ						Ẅ
0390	Î	Ħ	Ĭ	Γ	Δ	Ε	Ζ	Η	Θ	Ι	Κ	Λ	Μ	Ν	Ξ	Ο
Tiny font. Press ↑, ↓ or EXIT 34/41																

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
03A0	Π	Ρ		Σ	Τ	Υ	Φ	Χ	Ψ	Ω	İ	Ų	Ǻ	Ǽ	Ǿ	ı
03B0	Û	α	β	γ	δ	ε	ζ	η	θ	ι	κ	λ	μ	ν	ξ	ο
03C0	π	ρ	ς	σ	τ	υ	φ	χ	ψ	ω	ĩ	ü	ó	ú	ô	
03D0									Q	Q			F	F		
03E0	ᵐ	λ														
2000																
2010									‘	’	,	“	”	„	“	”
2020							...	1								
Tiny font.	Press ↑, ↓ or EXIT															35/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2070				E												
2080	0	1	2	3	4	5	6	7	8	9	+	-				*
2090															∞	∞
20A0													€			
2100			C												h	h
2110						H					Q			R		
2120					Z											
2140									i	j						
Tiny font. Press ↑, ↓ or EXIT																
																36/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2160	0	1	2	3	4	5	6	7	8	9	+	-				
2190	←	↑	→	↓		⊕										
21C0	→				±					△		▽	≡	≠		
21D0			⇒													
21E0	←	↑	→	↓				↑		↓						
2200		©	ð	☹	☹	☹	△	▽	€	¢		≡	⊗		□	π
2210				±					▪	▪	√	√	√	α	ω	ℓ
2220	∠	¼	½		†		‡	^	v	n	u	f	f	f	f	f
Tiny font. Press ↑, ↓ or EXIT																
																37/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2230	≠															
2240				≈					≈							
2250					≈				≈	≈						
2260	≠	≡			≤	≥					⊕	⊗				
2290						⊗	⊗	⊗	⊗	⊗	⊗					
22A0			⊥		⊥	⊥										
22B0												⊥	⊥	⊥		
22C0																
Tiny font. Press ↑, ↓ or EXIT																
																38/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2310											☉	⌚				
2380													↩			
2390										🏠						
23A0		┌	┐	└	┘	┌	┐									
23B0						└										
23F0		☉														
2420		↙	↗	└		↘	↗	⌘	⌘	;	📄	↑	☐	⌘	⌘	📄
2430	▲	↘	↙	▲	⤵											
Tiny font. Press ↑, ↓ or EXIT																
																39/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
2460	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
2470														10		
2480			a	b	c	d	e	f	g	h	i	j	k	l	m	n
2490	o	p	q	r	s	t	u	v	w	x	y	z	a	b	c	d
24A0	e	f	g	h	i	j	k	l	m	n	o	p	q	r	s	t
24B0	u	v	w	x	y	z	A	B	C	D	E	F	G	H	I	J
24C0	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z
24D0	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P
Tiny font. Press ↑, ↓ or EXIT																
																40/41

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
24E0	Q	R	S	T	U	V	W	X	Y	Z						
2670											Δ	C			N	
2710				✓												
2780									,	▪						
2B60	+	+	+	+												
					π	π	π									ϑ
Tiny font. Press ↑ or EXIT																
																41/41