

HPlot	Histogram					
g-shift						
f-shift						
unshifted	HNORM	-ZOOM ₀				
Page 1	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/R47/Menus/R47v0_Menu_HOME_page_1.pdf

Next menu https://47calc.com/doc/R47/Menus/R47v0_Menu_Hyper_page_1.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p1	HPLLOT	MENU	Histogram	Histogram plotting (programmable)	Plotting and statistics		HPLLOT	
F1	HNORM	Command	Histogram Normal	Fit Gauss distribution through HIST0 data (programmable)	Plotting and statistics		HNORM	
F2	-ZOOM0	Command	Zoom out on y-axis	Decrease zoom level on the y-axis (range -16 to +16) ; Info : <0 : zoom out ; 0 : normal ; >0 : zoom in ; -ZOOM resets ↑Y and ↑Y to zero	Plotting			0
F3								
F4								
F5								
F6								
fF1								
fF2								
fF3								
fF4								
fF5								
fF6								
gF1								
gF2								
gF3								
gF4								
gF5								
gF6								