

Power:	Power conversions					
g-shift						
f-shift						
unshifted	W ←	→ hp _E	W ←	→ hp _{UK}	W ←	→ hp _M
Page 1	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/R47/Menus/R47v0_Menu_Poiss_page_1.pdf

Next menu https://47calc.com/doc/R47/Menus/R47v0_Menu_PREF_page_1.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p1	Power:	MENU	Power conversions	Convert between units of power ; Info : Flag CONV _{HP} may be SET for <to> $\leftrightarrow$ <to> unit conversion buttons ; CLEAR for <from> $\rightarrow \leftarrow$ <from> unit conversion buttons (default SET)	Power conversions		Power:	
F1	hp _E $\rightarrow$ W (W $\leftarrow$)	Function (monadic, linked)	hp _E to W	Convert electrical horsepower to Watt ; TI : W:	Power conversions	CONV _{HP}		
F2	W $\rightarrow$ hp _E ($\rightarrow$ hp _E)	Function (monadic, linked)	W to hp _E	Convert Watt to electrical horsepower ; TI : hp _E :	Power conversions	CONV _{HP}		
F3	hp _{UK} $\rightarrow$ W (W $\leftarrow$)	Function (monadic, linked)	hp _{UK} to W	Convert UK horsepower to Watt ; TI : W:	Power conversions	CONV _{HP}		
F4	W $\rightarrow$ hp _{UK} ($\rightarrow$ hp _{UK})	Function (monadic, linked)	W to hp _{UK}	Convert Watt to UK horsepower ; TI : hp _{UK} :	Power conversions	CONV _{HP}		
F5	hp _M $\rightarrow$ W (W $\leftarrow$)	Function (monadic, linked)	hp _M to W	Convert metric horsepower to Watt ; TI : W:	Power conversions	CONV _{HP}		
F6	W $\rightarrow$ hp _M ($\rightarrow$ hp _M)	Function (monadic, linked)	W to hp _M	Convert Watt to metric horsepower ; TI : hp _M :	Power conversions	CONV _{HP}		
fF1								
fF2								
fF3								
fF4								
fF5								
fF6								
gF1								
gF2								
gF3								
gF4								
gF5								
gF6								