

TamKey	TAM mode (KEY)					
g-shift	13	14	15	16	17	18
f-shift	7	8	9	10	11	12
unshifted	1	2	3	4	5	6
Page 1	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/R47/Menus/R47v0_Menu_TamIndirect_page_1.pdf

Next menu https://47calc.com/doc/R47/Menus/R47v0_Menu_TamLabel_page_1.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p1	TamKey	MENU (TAM)	TAM mode (KEY)	Transient Alpha Mode is activated for trailing input (KEYG, KEYX) ; Info : TamKey menu is typically activated by	Trailing input			
F1	1	Button (black)	Button 1	Soft button 1 for selection by KEYG or KEYX command	Programming			
F2	2	Button (black)	Button 2	Soft button 2 for selection by KEYG or KEYX command	Programming			
F3	3	Button (black)	Button 3	Soft button 3 for selection by KEYG or KEYX command	Programming			
F4	4	Button (black)	Button 4	Soft button 4 for selection by KEYG or KEYX command	Programming			
F5	5	Button (black)	Button 5	Soft button 5 for selection by KEYG or KEYX command	Programming			
F6	6	Button (black)	Button 6	Soft button 6 for selection by KEYG or KEYX command	Programming			
fF1	7	Button (black)	Button 7	Soft button 7 for selection by KEYG or KEYX command	Programming			
fF2	8	Button (black)	Button 8	Soft button 8 for selection by KEYG or KEYX command	Programming			
fF3	9	Button (black)	Button 9	Soft button 9 for selection by KEYG or KEYX command	Programming			
fF4	10	Button (black)	Button 10	Soft button 10 for selection by KEYG or KEYX command	Programming			
fF5	11	Button (black)	Button 11	Soft button 11 for selection by KEYG or KEYX command	Programming			
fF6	12	Button (black)	Button 12	Soft button 12 for selection by KEYG or KEYX command	Programming			
gF1	13	Button (black)	Button 13	Soft button 13 for selection by KEYG or KEYX command	Programming			
gF2	14	Button (black)	Button 14	Soft button 14 for selection by KEYG or KEYX command	Programming			
gF3	15	Button (black)	Button 15	Soft button 15 for selection by KEYG or KEYX command	Programming			
gF4	16	Button (black)	Button 16	Soft button 16 for selection by KEYG or KEYX command	Programming			
gF5	17	Button (black)	Button 17	Soft button 17 for selection by KEYG or KEYX command	Programming			
gF6	18	Button (black)	Button 18	Soft button 18 for selection by KEYG or KEYX command	Programming			