

TamMenu	TAM mode					
g-shift						
f-shift						
unshifted	→	MENU	→X	→Y	→Z	→T
Page 1	F1	F2	F3	F4	F5	F6

Prev menu https://47calc.com/doc/R47/Menus/R47v0_Menu_TamLocalLabel_page_1.pdf

Next menu https://47calc.com/doc/R47/Menus/R47v0_Menu_TamNonReg_page_1.pdf

Level	Label	Type	FullName	Extended description	Category	Flag	Catalog	Default
Menu p1	TamMenu	MENU (TAM)	TAM mode	Transient Alpha Mode is activated for trailing input (menu selection) ; Info : α (f[XEQ]) or TAM [XEQ] activates TamAlpha ; Indirection (→) activates TamIndirect ; TamMenu menu is typically activated by OPENM on [P.FN2.1] fF4	Trailing input			
F1	→	Command (TAM)	Indirection	Presented in TAM menus for commands accessing indirect input ; Info : Opens TamIndirect menu for the command that activated the current TAM menu	Trailing input			
F2	MENU	MENU (ASM)	Menu	Presented in menu TamMenu for commands accessing menus ; Info : Type characters 1-2 to search	Trailing input		MENU	
F3	→X	Command (TAM)	Indirect X	Presented in TAM menus for commands accessing indirect input using stack register X	Trailing input			
F4	→Y	Command (TAM)	Indirect Y	Presented in TAM menus for commands accessing indirect input using stack register Y	Trailing input			
F5	→Z	Command (TAM)	Indirect Z	Presented in TAM menus for commands accessing indirect input using stack register Z	Trailing input			
F6	→T	Command (TAM)	Indirect T	Presented in TAM menus for commands accessing indirect input using stack register T	Trailing input			
fF1								
fF2								
fF3								
fF4								
fF5								
fF6								
gF1								
gF2								
gF3								
gF4								
gF5								
gF6								

p1	TamMenu	Link
F1	→	
F2	MENU	https://47calc.com/doc/R47/Menus/R47v0_Menu_MENU_page_1.pdf
F3	→X	
F4	→Y	
F5	→Z	
F6	→T	
fF1		
fF2		
fF3		
fF4		
fF5		
fF6		
gF1		
gF2		
gF3		
gF4		
gF5		
gF6		