

R47v0 Ref page : KEYMAP in menu [CAT.1]fF6

R47v0primaryNM

unshifted keyboard mapping (USER KEYS)					
x^2	$\sqrt{x}$	$1/x$	y^x	LOG	LN
STO	RCL	R↓	DRG	f	g
ENTER		$x\frac{\Box}{\Box}y$	CHS	EEX	←
XEQ	7	8	9	÷	
↑	4	5	6	×	
↓	1	2	3	-	
EXIT	0	.	R/S	+	
[↑] [↓] Browse - [.] Toggle STD/USER View					

Browse keyboard map (default USER mode) ; also showing special NORMAL hotkey assignment from menu □ KEY ; if KEYMAP is activated when in Alpha Input Mode or Equation Input Mode, the alpha keyboard mappings are shown only (default NORMAL mode, starting with alpha g-shift) ; Press and hold key [.] to view USER or NORMAL (STD) keys ; browse using [↑] and [↓] ; press [EXIT] to exit Keyboard map ; NORMAL keys show dimmed in USER view