

<b>Dist:</b>	Distance conversion MENU - cat : Dist:	Convert between units of distance	Category: Unit conversion
--------------	--	-----------------------------------	---------------------------

page scrolling indicator : ▲ ▼

Menu	Dist:	1	2	3	4	5	6
3	gShifted						
2	fShifted	nmi →	← km	fathom →	← m		
1	primary	mi. →	← km	surveyft.us →	← m	point →	← mm
Page	3	F1	F2	F3	F4	F5	F6

--	--	--	--	--	--	--	--

Dist:	Page 3	F-key	Button label	Full name	Extended description	Type	Flag name	Additional information	Catalog	Default	Status
F1			mi. → km	mi. to km	Convert mile to kilometer	Function (linked)		TI : km:	mi.→km		LeftLink
F2			km → mi.	km to mi.	Convert kilometer to mile	Function (linked)		TI : mi.:	km→mi.		RightLink
F3			surveyft.us → m	surveyft.us to m	Convert US survey foot to meter	Function (linked)		TI : m:	ftus→m		LeftLink
F4			m → surveyft.us	m to surveyft.us	Convert meter to US survey foot	Function (linked)		TI : ftus:	m→ftus		RightLink
F5			point → mm	point to mm	Convert point to millimeter	Function (linked)		TI : mm:	pt.→mm		LeftLink
F6			mm → point	mm to point	Convert millimeter to point	Function (linked)		TI : pt.:	mm→pt.		RightLink

fShifted F1	nmi → km	nmi to km	Convert nautical mile to kilometer	Function (linked)		TI : km:	nmi→km		LeftLink
fShifted F2	km → nmi	km to nmi	Convert kilometer to nautical mile	Function (linked)		TI : nmi:	km→nmi		RightLink
fShifted F3	fathom → m	fathom to m	Convert fathom to meter	Function (linked)		TI : m:	fm.→m		LeftLink
fShifted F4	m → fathom	m to fathom	Convert meter to fathom	Function (linked)		TI : fm.:	m→fm.		RightLink
fShifted F5	<empty>								
fShifted F6	<empty>								

gShifted F1	<empty>								
gShifted F2	<empty>								
gShifted F3	<empty>								
gShifted F4	<empty>								
gShifted F5	<empty>								
gShifted F6	<empty>								