

Power:	Power conversion MENU - cat : Power:	Convert between units of power	Category: Unit conversion
---------------	--------------------------------------	--------------------------------	---------------------------

Menu	Power:	1	2	3	4	5	6
3	gShifted						
2	fShifted						
1	primary	hp _E →	← W	hp _{UK} →	← W	hp _M →	← W
Page	1	F1	F2	F3	F4	F5	F6

--	--

Power:	Page 1								
F-key	Button label	Full name	Extended description	Type	Flag name	Additional information	Catalog	Default	Status
F1	hp _E → W	hp _E to W	Convert electrical horsepower to Watt	Function (linked)		TI : W:	hp _E →W		LeftLink
F2	W → hp _E	W to hp _E	Convert Watt to electrical horsepower	Function (linked)		TI : hp _E :	W→hp _E		RightLink
F3	hp _{UK} → W	hp _{UK} to W	Convert UK horsepower to Watt	Function (linked)		TI : W:	hp _{UK} →W		LeftLink
F4	W → hp _{UK}	W to hp _{UK}	Convert Watt to UK horsepower	Function (linked)		TI : hp _{UK} :	W→hp _{UK}		RightLink
F5	hp _M → W	hp _M to W	Convert metric horsepower to Watt	Function (linked)		TI : W:	hp _M →W		LeftLink
F6	W → hp _M	W to hp _M	Convert Watt to metric horsepower	Function (linked)		TI : hp _M :	W→hp _M		RightLink

fShifted F1	<empty>								
fShifted F2	<empty>								
fShifted F3	<empty>								
fShifted F4	<empty>								
fShifted F5	<empty>								
fShifted F6	<empty>								

gShifted F1	<empty>								
gShifted F2	<empty>								
gShifted F3	<empty>								
gShifted F4	<empty>								
gShifted F5	<empty>								
gShifted F6	<empty>								