

Σ+NRM	Special key assignments MENU - cat : I	Submenu for special key assignments to Sigma+ key in normal mode	Category: Keyboard
--------------	--	--	--------------------

Menu	Σ+NRM	1	2	3	4	5	6
3	gShifted						
2	fShifted	ΣPRGM ()	ΣUSER ()	ΣHOME ()	Σ+ (+)	ΣSNAP ()	
1	primary	Σα ()	ΣCC ()	Σg ()	ΣMyM ()	ΣDRG ()	COPY→U
Page	1	F1	F2	F3	F4	F5	F6

--	--	--	--	--	--	--	--

Σ+NRM	Page 1	F-key	Button label (complete)	Full name	Extended description	Type	Flag name	Additional information	Catalog	Default	Status
F1			Σα	Σα	Assign α to Σ+ key for NORMAL mode ONLY & deactivate USER mode	Setting	<no flag>	Info : Shown in KEYMAP as [α] (in reverse)		OFF	Radiobutton
F2			ΣCC	ΣCC	Assign CC to Σ+ key for NORMAL mode ONLY & deactivate USER mode	Setting	<no flag>	Info : Shown in KEYMAP as [CC] (in reverse)		OFF	Radiobutton
F3			Σg	Σg	Assign [G] to Σ+ key for NORMAL as well as USER mode ; disables longpress on Σ+ and the use of this key as A in ASM 2-character search ; shift keys are not assignable to any key in USER mode	Setting	<no flag>	Info : Shown in KEYMAP as [G] (in reverse)		OFF	Radiobutton
F4			ΣMyM	ΣMyM	Assign MyMenu to Σ+ key for NORMAL mode ONLY & deactivate USER mode	Setting	<no flag>	Info : Shown in KEYMAP as [MyM] (in reverse)		OFF	Radiobutton
F5			ΣDRG	ΣDRG	Assign DRG to Σ+ key for NORMAL mode ONLY & deactivate USER mode	Setting	<no flag>	Info : Shown in KEYMAP as [DRG] (in reverse)		OFF	Radiobutton
F6			COPY→U	Copy Σ+NRM assignment to USER	Copy Σ+ NORMAL assignment to USER mode assignment and activate USER mode	Command		Info : Does not copy Σg assignment			

fShifted F1			ΣPRGM	ΣPRGM	Assign PRGM to Σ+ key for NORMAL mode ONLY & deactivate USER mode	Setting	<no flag>	Info : Shown in KEYMAP as [PRGM] (in reverse)		OFF	Radiobutton
fShifted F2			ΣUSER	ΣUSER	Assign USER to Σ+ key for NORMAL mode ONLY & deactivate USER mode	Setting	<no flag>	Info : Shown in KEYMAP as [USER] (in reverse)		OFF	Radiobutton
fShifted F3			ΣHOME	ΣHOME	Assign HOME to Σ+ key for NORMAL mode ONLY & deactivate USER mode	Setting	<no flag>	Info : Shown in KEYMAP as [HOME] (in reverse)		OFF	Radiobutton
fShifted F4			Σ+	Σ+	Assign Σ+ to Σ+ key for NORMAL mode ONLY & deactivate USER mode	Setting	<no flag>	Info : Shown in KEYMAP as Σ+ (normal)		ON	Radiobutton
fShifted F5			ΣSNAP	ΣSNAP	Assign SNAP to Σ+ key for NORMAL mode ONLY & deactivate USER mode	Setting	<no flag>	Info : Shown in KEYMAP as [SNAP] (in reverse)		OFF	Radiobutton
fShifted F6			<empty>								

gShifted F1			<empty>								
gShifted F2			<empty>								
gShifted F3			<empty>								
gShifted F4			<empty>								
gShifted F5			<empty>								
gShifted F6			<empty>								