

<b>TamStoRclAlpha</b>	TAM mode STORCL/alpha MENU (TAM)	Transient alpha mode is activated for trailing input (STO, RCL + alpha)	Category: Trailing input
-----------------------	----------------------------------	---	--------------------------

Menu	TamStoRclAlpha	1	2	3	4	5	6
3	gShifted	...EL	...IJ	Myα	A..Ω	α*	αMATH
2	fShifted	Config	Stack	N [ ]	C [·]	Max	Min
1	primary	→	VAR	X	Y	Z	T
Page	1	F1	F2	F3	F4	F5	F6

Info Activated from TamStoRcl by AIM (a)

TamStoRclAlpha	Page 1	F-key	Button label	Full name	Extended description	Type	Flag name	Additional information	Catalog	Default	Status
		F1	→	Indirection	Presented in TAM menus for commands accessing indirect input	Function (TAM)					
		F2	VAR	VAR	Presented in TAM menus for commands accessing variables	MENU (TAM, ASM)		TAM : CAT.VARS.+ menu ; Type characters 1-2 to search	VAR		
		F3	X	X-register	Presented in TAM menus for commands accessing stack level X	Function (TAM)					
		F4	Y	Y-register	Presented in TAM menus for commands accessing stack level Y	Function (TAM)					
		F5	Z	Z-register	Presented in TAM menus for commands accessing stack level Z	Function (TAM)					
		F6	T	T-register	Presented in TAM menus for commands accessing stack level T	Function (TAM)					

fShifted F1	Config	STO/RCL configuration	Presented in TAM menus when STO/RCL is active to quickly select STOCFG/RCLCFG (STO/RCL Configuration)	Function (TAM)		TAM : STOCFG/RCLCFG __ TamStoRcl(Alpha) menu				
fShifted F2	Stack	STO/RCL stack	Presented in TAM menus when STO/RCL is active to quickly select STOS/RCLS (STO/RCL Stack)	Function (TAM)		TAM : STOS/RCLS __ TamStoRcl(Alpha)				
fShifted F3	N	Numlock	Numlock	Setting	<no flag>				OFF	Checkbox
fShifted F4	C	Capslock	Lock uppercase alpha input	Setting	αCAP	SBI : A ; a ; Info : Toggling clears Numlock			ON	Checkbox
fShifted F5	Max	STO/RCL maximum	Presented in TAM menus when STO/RCL is active to quickly select STO Up/RCL Up (STO/RCL maximum of x and source)	Function (TAM)		TAM : STO↑ __ TamStoRcl(Alpha) menu				
fShifted F6	Min	STO/RCL minimum	Presented in TAM menus when STO/RCL is active to quickly select STO Dn/RCL Dn (STO/RCL minimum of x and source)	Function (TAM)		TAM : STO↓ __ TamStoRcl(Alpha) menu				

gShifted F1	...EL	...EL	Presented in TAM menus for commands accessing matrix element	Function (TAM)						
gShifted F2	...IJ	...IJ	Presented in TAM menus for commands accessing matrix index	Function (TAM)						
gShifted F3	Myα	MyAlpha	MyAlpha is where to assign special characters for easy entry	MENU				Myα		
gShifted F4	A..Ω	ALPHA..OMEGA	Uppercase Greek characters	MENU		Info : Lowercase menu via [▼]	A..Ω			
gShifted F5	α*	Alpha dot	Special characters	MENU			α*			
gShifted F6	αMATH	Alpha Math	Mathematical symbols	MENU			αMATH			